

Installation Instructions For Vacuum Lock Safety Wall Fitting

安全锁吸污口安装说明书



1. Thread the fitting into a 1 ½" port in the pool wall. Make sure that you end with the cover spring as close to 12 o'clock as possible (see Figure 1). NOTE: This fitting is designed for a threaded pipe connection only.
2. When the fitting is tight and the spring in the 12 o'clock position, tighten the set screw (included) to hold it in place (see Figure 2).
3. Open the door with a key or screwdriver. Insert the hose so that the grooves in the hose interlock with the tab on the Vac-Lock door (see Figure 3). This will prevent the hose from squirting out of the fitting when the pump is stopped.

WARNING: Pump suction is hazardous and can trap, drown and/or disembowel bathers. Do not use or operate swimming pools, spas or hot tubs if a suction outlet cover is missing, broken or loose.

NOTE: The installation of a Vac-Lock Fitting by closing of the suction line reduces the potential hazard caused by an open accessible source of suction.

NOTE: If any part of this fitting is broken, damaged, missing, or not working properly, replace the entire fitting. It is not designed to be repaired.

IMPORTANT NOTES

- Only open the door when the pump/filter system is off. A key or screwdriver is required. You will not be able to open the door when the pump/filter system is operating.
- The pump may activate (causing damage to the pump) if the hose is removed and the Vac-Lock is allowed to shut with no other suction sources open. Do not remove the hose from the Vac-Lock unless another source of suction is open.

WARNING: Entrapment and injury hazard from spring-loaded door. Allowing the Vac-Lock door to snap shut can trap hair or injure fingers.

WARNING: Risk of hair and/or body entrapment on end of suction hose.

安装1.5英寸NPT管件

1. 将连接件穿入池壁的1.5英寸的管件。确保你在拧入结束时与盖弹簧尽可能接近12点钟方向（如图1）。这种接头只适用于有头的管道连接。
2. 当连接件是紧密的和弹簧在12点钟的位置时，用紧固固定螺丝使其到位。（如图2）
3. 用钥匙或螺丝刀打开面盖、插入软管，软管上的凹槽于真空锁门上的标签一起紧固（如图3）。这防止软管在泵停止时从连接件中喷射出来。

警告：泵吸是危险的，切勿使用于正在开放的游泳池、温泉浴场或热水浴缸，以免吸入口盖遗失、破裂或松动。

注意：通过关闭吸入管路来安装真空锁配件，可以减少由于开放的可接近的吸入源所造成的潜在危险。

注意：如果配件的任何部分破损、损坏、丢失或不能正常工作，请更换整个连接件。


重要注意事项

当泵/过滤器工作时，如果软管被拆卸，并且真空锁被允许在没有其他吸入源打开的情况下关闭，则泵可能被激活（对泵造成损坏），因此你将无法打开阀门。除非另一个吸力源打开，否则不要从真空锁上拆卸软管。

警告：弹簧门夹持及伤害危险。


让真空门锁啪的一声关上可能会夹住头发或伤到手指。

警告：吸入软管末端有头发和身体被夹住的危险。




Thread Vac-Lock into port in pool wall.
将真空锁拧入池壁的端口

Figure 1
图1



Fasten in upright position using set-screw.
使用定位螺丝将其固定在正确的位置

Figure 2
图2



Engage tab in grooves in hose.
使标签卡在软管上的凹槽中

Figure 3
图3